
# Assembly Instructions: 6070-FM (Tribeca)

#### IMPORTANT:

- ALL INSTALLATION WORK SHOULD BE DONE BY ACCREDITED PROFESSIONAL.
- SHUT OFF POWER SUPPLY AT FUSE OR CIRCUIT BREAKER!
- USE ONLY THE SPECIFIED BULBS. DO NOT EXCEED THE MAXIMUM WATTAGE!

For Customer Service, please contact the place of purchase.




### PREPARING FOR INSTALLATION

Remove all of the contents from the carton. See the important notes above. Remove the old fixture from the ceiling, including the old mounting strap.

- 1. From the parts bag remove the mounting strap assembly. One end of nipple (F) should be attached to mounting strap (A) with hex nut (C) and washer (D) in place. Test mounting strap (A) against ceiling pan (H) to ensure that deco nut (G) may be threaded on tightly. Remove the deco nut and place the fixture aside.
- 2. Attach mounting strap (A) to the junction box using mounting screws (B) and a screwdriver. Tighten securely.
- 3. Frame (K) is composed of four panels (1 and 2). The panels are two different sizes. Slide panels (1) over the ends of connected panels (2) so that the holes in panels (1) line up with the holes in panels (2). Use screws (J) to secure the panels together. Frame (K) should look like the diagram below when completed.

#### **CONNECTING THE WIRES**

4. Thread the fixture's wires through nipple (F). Refer to the wiring diagram and attach the fixture's wires to the power supply wires from the junction box. Connect Hot to Hot, Neutral to Neutral, and Ground to Ground. Twist the ends of the wire pairs together, and then twist on a wire connector. Make sure all twists are in the same direction. If there is no house ground wire coming from the junction box, locate ground screw (E) on the mounting bracket/mounting strap and wrap the fixture's ground wire around the ground screw. Use a screwdriver to tighten the top of ground screw (E) onto the wires and into the mounting bracket/mounting strap. Tuck the wires into the junction box.



How to Identify the Fixture's Wires			House Wire
<u>Hot</u>	<u>Neutral</u>	Ground	Fixed Wires Neutral
Smooth	Ribbed	Bare Metal, Green, or Green Inner Thread	
Black	White		Neutral — Groun
Black Inner Thread	White Inner Thread		Ground —

## FINISHING THE INSTALLATION

- 5. Push the ceiling pan up to the ceiling and thread finial (G) onto the threads of nipple (F) to secure the ceiling pan in place.
- 6. Install light bulbs (not provided) in accordance with the fixture's specifications. Do not exceed the maximum wattage.

Your installation is now complete. Turn on the power and test the fixture.

#### **CLEANING TIPS**

Treat the fixture gently! Regular cleaning will reduce the need for deep cleaning. For regular cleaning, turn off the light and wipe down the fixture with a clean lint-free cotton or microfiber cloth. Never spray cleaner directly onto the fixture.

